

LONDON BUSES - ROUTE DESCRIPTION

ROUTE H32: Hounslow - Southall

Date of Service Change: 18 March 2023.

STREETS TRAVERSED

Towards Southall: Hounslow Bus Station, Kingsley Road, Hounslow High Street, Hanworth Road, Grove Road, Bell Road, Lampton Road, Bath Road, Vicarage Farm Road, North Hyde Lane, Convent Way, North Hyde Lane, Convent Way, Wentworth Road, Western Road, King Street, The Green, South Road, Hamilton Road, Avenue Road

Towards Hounslow: Avenue Road, Cambridge Road, South Road, The Green, King Street, Montague Way, Western Road, Wentworth Road, Convent Way, North Hyde Lane, Vicarage Farm Road, Bath Road, Hounslow West Station Forecourt, Bath Road, Steve Biko Way, Staines Road, Grove Road, Hanworth Road, Hounslow High Street, London Road, Hounslow Bus Station

AUTHORISED STANDS, CURTAILMENT POINTS, & BLIND DESCRIPTIONS

Please note that only stands, curtailment points, & blind descriptions as detailed in this contractual document may be used.

Hounslow Bus Station

Private stand for 9 buses in marked bays in bus parking area in Hounslow Bus Station on north side of London Road.

Buses proceed from London Road, Hounslow Bus Station to stand, departing via Hounslow Bus Station, Kingsley Road to Hounslow High Street.

Set down in London Road, at Stop Z1 (33528 - Hounslow Bus Station) and pick up in High Street, at Stop C (BP4837 - School Road).

AVAILABILITY:	At any time.
OPERATING RESTRICTIONS:	No more than 2 buses on Route H32 should be scheduled to stand at any one time.
MEAL RELIEFS:	No meal relief vehicles to stand at any time.
FERRY VEHICLES:	No ferry vehicles to park on stand at any time.
BLIND DISPLAY:	Hounslow Bus Station.

Hounslow, Steve Biko Stand (from Southall, Town Hall)

Buses proceed from Bath Road, Steve Biko Way, Staines Road, Hospital Road departing to Bath Road.

Set down in Bath Road, at stop G (16335 - St Michael & St Martin Church) and pick up in Bath Road, at Stop H (16336 - St Michael & St Martin Church).

AVAILABILITY:	At any time.
OPERATING RESTRICTIONS:	Turning Point Only - Buses must not stand
BLIND DISPLAY:	Hounslow, Bell Corner .

Hounslow West Station (from Hounslow Bus Station)

Private stand for one bus in station forecourt commencing at lamp standard N801 extending 16 metres northwest.

From Hounslow Bus Station

Buses proceed from Bath Road, Hounslow West Station Forecourt to stand, departing via Hounslow West Station Forecourt, Bath Road to Hounslow West Station Forecourt. Set down in Bath Road, at Stop K (16388 - St Paul's Church) and pick up in Hounslow West Station Forecourt, at Stop A (9115 - Hounslow West Station).

From SOUTHALL, TOWN HALL

Buses proceed from Hounslow West Station Forecourt to stand, departing via Hounslow West Station Forecourt, Bath Road to Vicarage Farm Road.

Set down in Hounslow West Station Forecourt, at Stop A (9115 - Hounslow West Station) and pick up in Vicarage Farm Road, at Stop D (15672 - Hounslow West Stn / Vicarage Farm Rd).

AVAILABILITY:	At any time.
OPERATING RESTRICTIONS:	Unscheduled curtailments only.
MEAL RELIEFS:	No meal relief vehicles to stand at any time.
FERRY VEHICLES:	No ferry vehicles to park on stand at any time.
BLIND DISPLAY:	Hounslow West.

Heston, Cranford Lane

From Hounslow

Buses proceed from Vicarage Farm Road, New Heston Road, Heston Road, New Heston Road departing to Vicarage Farm Road.

Set down in Vicarage Farm Road, at Stop VC (16206 - Cranford Lane) and pick up in Vicarage Farm Road, at Stop VK (16205 - Cranford Lane).

From Southall

Buses proceed from North Hyde Lane, Vicarage Farm Road, New Heston Road, Heston Road, New Heston Road, Vicarage Farm Road departing to North Hyde Lane. Set down in North Hyde Lane, at Stop VJ (27892 - New Heston Road) and pick up in North Hyde Lane, at Stop VE (27891 - New Heston Road).

AVAILABILITY: At any time.
OPERATING RESTRICTIONS: **Turning Point Only - Buses must not stand**
BLIND DISPLAY: Heston, Cranford Lane.

Southall, King Street (from Hounslow Bus Station)

Buses proceed from Western Road departing to King Street.

Set down in Western Road, At Stop H (C98 - Waltham Road) and pick up in King Street, At Stop F (8748 - King Street).

AVAILABILITY: At any time.
OPERATING RESTRICTIONS: **Turning Point Only - Buses must not stand**
BLIND DISPLAY: Southall, King Street.

Southall, the Green (from Hounslow Bus Station)

Buses proceed from The Green, South Road departing to The Green.

Set down in The Green, at Stop L (19033 - The Green) and pick up in The Green, at Stop M (8750 - The Green).

AVAILABILITY: At any time.
OPERATING RESTRICTIONS: **Turning Point Only - Buses must not stand**
BLIND DISPLAY: Southall, The Green.

Southall, Town Hall, Avenue Road

Public stand for six buses in two parts:

1 - Main stand for 3 buses in layby on east side of Avenue Road, commencing 28 metres south of Boyd Avenue and extending 18 metres north.

2 - Overflow stand for 3 buses on south side of Cambridge Road commencing 48 metres west of Avenue Road and extending 28 metres east.

Buses proceed from South Road, Hamilton Road, Avenue Road to stand, departing via Avenue Road, Cambridge Road to South Road.

Set down in Hamilton Road, at Alighting Point (34558 - Southall Town Hall) and pick up in South Road, at Stop M (20712 - Southall Broadway).

AVAILABILITY:	At any time.
OPERATING RESTRICTIONS:	No more than 1 bus on Route H32 should be scheduled to stand at any one time.
MEAL RELIEFS:	No meal relief vehicles to stand at any time.
FERRY VEHICLES:	No ferry vehicles to park on stand at any time.
BLIND DISPLAY:	Southall, Town Hall.
OTHER INFORMATION:	Buses should use the stand in Avenue Road unless full. An overflow stand is available in Cambridge Road. Care should be taken not to obstruct the vehicular entrances to the British Telecom building.

Route H32

Route Record

Hounslow Bus Station - Southall - Town Hall

Start Date: 03 September 2016

Reason for Issue: Updated Jan 2022

Streets Traversed:

Towards Southall, Town Hall:

Hounslow High Street, Hanworth Road, Grove Road, Bell Road, Bath Road, Vicarage Farm Road, North Hyde Lane, Convent Way, Wentworth Road, Western Road, King Street, The Green, South Road, Hamilton Road.

Towards Hounslow Bus Station:

South Road, The Green, King Street, Montague Way, Western Road, Wentworth Road, Convent Way, North Hyde Lane, Vicarage Farm Road, New Heston Road, Vicarage Farm Road, Bath Road, Hounslow West Station Forecourt, Bath Road, Steve Biko Way, Staines Road, Grove Road, Hanworth Road, Hounslow High Street, London Road.

Please Note:

The route record, including streets traversed, stand workings and blind descriptions should be followed at all times, except for short term diversions or emergencies. Garage journeys are approved by Garage Risk Managers and are part of the Route Risk Assessments.

Any errors or corrections to this document MUST be advised to the Business Development section.

Stands and Turning Points

Hounslow Bus Station

Private stand for 9 buses in marked bays in bus parking area in Hounslow Bus Station on north side of London Road.

Buses proceed from London Road via Hounslow Bus Station to stand, departing via Hounslow Bus Station and Kingsley Road to Hounslow High Street. Set down in London Road, at Stop Z1 and pick up in Hounslow High Street, at Stop C.

AVAILABILITY:	At any time
OPERATING RESTRICTIONS:	No more than 2 buses on Route H32 to be scheduled to Stand at any one time
MEAL RELIEFS:	No meal relief vehicles to stand at any time
FERRY VEHICLES:	No ferry vehicles to park on stand at any time
DISPLAY:	Hounslow Bus Station

Hounslow - Bell Corner (from Southall, Town Hall)

Private stand for 3 buses in separate 12-metre marked bays in Bus Parking Area on north side of Bath Road adjacent to Bath Road Car Park and opposite Nos. 22-36.

Buses proceed from Staines Road via Grove Road, Bell Road, Bath Road and Bell Corner to stand, departing via Bell Corner to Bath Road. Set down in Staines Road, at Stop V (BP931 - The Bell, Last Stop on LOR: BP931 - The Bell) and pick up in Bath Road, at Stop H (16336 - St Michael & St Martin Church, First Stop on LOR: 16336 - St Michael & St Martin Church).

AVAILABILITY:	At any time
OPERATING RESTRICTIONS:	Unscheduled curtailments only
MEAL RELIEFS:	No meal relief vehicles to stand at any time
FERRY VEHICLES:	No ferry vehicles to park on stand at any time
DISPLAY:	Hounslow - Bell Corner

Hounslow West Station

Private stand for one bus in station forecourt commencing at lamp standard N801 extending 16 metres northwest.

From Hounslow Bus Station.

Buses proceed from Bath Road via Hounslow West Station Forecourt to stand, departing to Hounslow West Station Forecourt. Set down in Bath Road, at Stop K (16388 - St Paul's Church, Last Stop on LOR: 16388 - St Paul's Church) and pick up in Hounslow West Station Forecourt, at Stop A (9115 - Hounslow West Station, First Stop on LOR: 9115 - Hounslow West Station).

From Southall - Town Hall.

Buses proceed from Hounslow West Station Forecourt direct to stand, departing via Hounslow West Station Forecourt and Bath Road to Vicarage Farm Road. Set down in Hounslow West Station Forecourt, at Stop A (9115 - Hounslow West Station, Last Stop on LOR: 9115 - Hounslow West Station) and pick up in Vicarage Farm Road, at Stop D (15672 - Hounslow West Station, First Stop on LOR: 15672 - Hounslow West Station).

AVAILABILITY:	At any time
OPERATING RESTRICTIONS:	Unscheduled curtailments only
MEAL RELIEFS:	No meal relief vehicles to stand at any time
FERRY VEHICLES:	No ferry vehicles to park on stand at any time
DISPLAY:	Hounslow West

Convent Way Estate (from Hounslow Bus Station)

Buses proceed from Convent Way via Wentworth Road, Western Road and Wentworth Road departing to Convent Way. Set down in Convent Way, at Stop BN (34590 - Wentworth Road, Last Stop on LOR: 34590 - Wentworth Road) and pick up in Convent Way, at Stop BH (34589 - Wentworth Road, First Stop on LOR: 34589 - Wentworth Road).

AVAILABILITY:	At any time
OPERATING RESTRICTIONS:	TURNING POINT ONLY - BUSES MUST NOT STAND
DISPLAY:	Convent Way

Southall - The Green (from Hounslow Bus Station)

Buses proceed from The Green via South Road, A3005 and South Road departing to The Green. Set down in The Green, at Stop L (19033 - The Green, Last Stop on LOR: 19033 - The Green) and pick up in The Green, at Stop M (8750 - The Green, First Stop on LOR: 8750 - The Green).

AVAILABILITY:	At any time
OPERATING RESTRICTIONS:	TURNING POINT ONLY - BUSES MUST NOT STAND
DISPLAY:	Southall - The Green

Southall - Town Hall - Avenue Road

Public stand in three parts:

1 - Main stand in bay on east side of Avenue Road, commencing 28 metres south of Boyd Avenue and extending 18 metres north.

2 - Overflow stand on south side of Cambridge Road commencing 48 metres west of Avenue Road and extending 28 metres east.

3 - Additional overflow stand on south side of Cambridge Road commencing 69 metres west of Avenue Road and extending 15 metres east.

Buses proceed from Hamilton Road via Avenue Road to stand, departing via Avenue Road and Cambridge Road to South Road. Set down in Hamilton Road, at Alighting Point (34558 - Southall Town Hall, Last Stop on LOR: 34558 - Southall Town Hall) and pick up in South Road, at Stop M (20712 - Southall Broadway, First Stop on LOR: 20712 - Southall Broadway).

AVAILABILITY:	At any time
OPERATING RESTRICTIONS:	No more than 1 bus on Route H32 should be scheduled to Stand at any one time. Buses should use the stand in Avenue Road unless full. An overflow stand is available in Cambridge Road. Care should be taken not to obstruct the vehicular entrances to the British Telecom building.
MEAL RELIEFS:	No meal relief vehicles to stand at any time
FERRY VEHICLES:	No ferry vehicles to park on stand at any time
DISPLAY:	Southall - Town Hall

Garage Journeys

From Hounslow Garage to Hounslow Bus Station:

From Hounslow Garage direct to Hounslow bus station stand.

From Hounslow Bus Station to Hounslow Garage:

From line of route via London Road to Hounslow Garage.

From Hounslow Garage to Southall Broadway - Town Hall:

From Hounslow Garage via Kingsley Road, Spring Grove Road, Lampton Road, Heston Road, Norwood Road, Merrick Road, South Road, Hamilton Road and Avenue Road to line of route.

From Southall Broadway, Town Hall to Hounslow Garage:

From line of route via Avenue Road, Cambridge Road, South Road, Merrick Road, Norwood Road, Heston Road, Lampton Road, Spring Grove Road, Kingsley Road and London Road to Hounslow Garage.

Streets Traversed:

Towards Southall, Town Hall:

Hounslow High Street, Hanworth Road, Grove Road, Bell Road, Bath Road, Vicarage Farm Road, North Hyde Lane, Convent Way, Wentworth Road, Western Road, King Street, The Green, South Road, Hamilton Road.

Towards Hounslow Bus Station:

South Road, The Green, King Street, Montague Way, Western Road, Wentworth Road, Convent Way, North Hyde Lane, Vicarage Farm Road, New Heston Road, Vicarage Farm Road, Bath Road, Hounslow West Station Forecourt, Bath Road, Steve Biko Way, Staines Road, Grove Road, Hanworth Road, Hounslow High Street, London Road.

Authorised Vehicle Types:

Double deck vehicles up to 10 m long. Single
Deck vehicles up to 10.2 m long.

Please Note:

The route record, including streets traversed, stand workings and blind descriptions should be followed at all times, except for short term diversions or emergencies. Garage journeys are approved by Garage Risk Managers and are part of the Route Risk Assessments.

Any errors or corrections to this document MUST be advised to the Business Development section.

Route H32 : Route Record

Hounslow Bus Station – Southall, Town Hall

Start Date : 3 December 2007

Reason for Issue : Opening of Hounslow Bus Station

Streets Traversed

Towards Southall, Town Hall:

Hounslow High Street, Hanworth Road, Grove Road, Bell Road, Bath Road, Vicarage Farm Road, North Hyde Lane, Convent Way, Wentworth Road, Western Road, King Street, The Green, South Road, Hamilton Road.

Towards Hounslow Bus Station:

South Road, The Green, King Street, Montague Waye, Western Road, Wentworth Road, Convent Way, North Hyde Lane, Vicarage Farm Road, New Heston Road, Vicarage Farm Road, Bath Road, Hounslow West Station Forecourt, Bath Road, Steve Biko Way, Staines Road, Grove Road, Hanworth Road, Hounslow HighStreet, London Road.

Stands And Turning Points

HOUNSLOW BUS STATION

Private stand for 9 buses in marked bays in bus parking area in Hounslow Bus Station on north side of London Road.

Buses proceed from London Road via Hounslow Bus Station to stand, departing via Hounslow Bus Station and Kingsley Road to Hounslow High Street. Set down in London Road, at Stop Z1 and pick up in Hounslow High Street, at Stop C.

AVAILABILITY: At any time.

OPERATING RESTRICTIONS: No more than 2 buses on Route H32 should be scheduled to stand at any one time.

MEAL RELIEFS: No meal relief vehicles to stand at any time.

FERRY VEHICLES: No ferry vehicles to park on stand at any time.

DISPLAY: Hounslow Bus Station.

HOUNSLOW, BELL CORNER (from Southall, Town Hall)

Public stand in LB Hounslow car park at junction of Lampton Road and Bath Road in two parts:

1) Commencing opposite No 24 Bath Road and extending 24 metres west.

2) Commencing opposite party wall of Nos 24/26 Bath Road and extending 12 metres west.

Buses proceed from Staines Road via Grove Road, Bell Road, Bath Road and Bell Corner to stand, departing via Bell Corner to Bath Road. Set down in Staines Road, at Stop V and pick up in Bath Road, at Stop H.

AVAILABILITY: At any time.

OPERATING RESTRICTIONS: Unscheduled curtailments only.

MEAL RELIEFS: No meal relief vehicles to stand at any time.

FERRY VEHICLES: No ferry vehicles to park on stand at any time.

DISPLAY: Hounslow, Bell Corner.

HOUNSLOW WEST STATION

Private stand for two buses in station forecourt.

From Hounslow Bus Station.

Buses proceed from Bath Road via Hounslow West Station Forecourt to stand, departing to Hounslow West Station Forecourt. Set down in Bath Road, at Stop K and pick up in Hounslow West Station Forecourt, at Stop A.

From Southall, Town Hall.

Buses proceed from Hounslow West Station Forecourt direct to stand, departing via Hounslow West Station Forecourt and Bath Road to Vicarage Farm Road. Set down in Hounslow West Station Forecourt, at Stop A and pick up in Vicarage Farm Road, at Stop D.

AVAILABILITY: At any time.
OPERATING RESTRICTIONS: Unscheduled curtailments only.
MEAL RELIEFS: No meal relief vehicles to stand at any time.
FERRY VEHICLES: No ferry vehicles to park on stand at any time.
DISPLAY: Hounslow West.

CONVENT WAY ESTATE (from Hounslow Bus Station)

Public stand in layby on south side of Convent Way, commencing opposite No.48 and extending eastwards.

Buses proceed from Convent Way direct to stand, departing via Convent Way, Wentworth Road, Western Road and Wentworth Road to Convent Way. Set down in Convent Way, at Stop BN and pick up in Convent Way, at Stop BJ.

AVAILABILITY: At any time.
OPERATING RESTRICTIONS: Unscheduled curtailments only.
MEAL RELIEFS: No meal relief vehicles to stand at any time.
FERRY VEHICLES: No ferry vehicles to park on stand at any time.
DISPLAY: Convent Way.

SOUTHALL, THE GREEN (from Hounslow Bus Station)

Buses proceed from The Green via South Road, A3005 and South Road departing to The Green. Set down in The Green, at Stop L and pick up in The Green, at Stop M.

AVAILABILITY: At any time.
OPERATING RESTRICTIONS: **Turning Point Only - Buses must not stand**
DISPLAY: Southall, The Green.

SOUTHALL, TOWN HALL, AVENUE ROAD

Public stand in two parts:

1 - In bay on east side of Avenue Road, commencing 10 metres south of Boyd Avenue and extending 18 metres south.

2 - Overflow stand on south side of Cambridge Road in two parts:

a - Commencing 20 metres west of Avenue Road and extending 28 metres west.

b - Commencing 54 metres west of Avenue Road and extending 15 metres west.

Buses proceed from Hamilton Road via Avenue Road to stand, departing via Avenue Road and Cambridge Road to South Road. Set down in Hamilton Road, at Alighting Point and pick up in South Road, at Stop M.

AVAILABILITY: At any time.
OPERATING RESTRICTIONS: No more than 1 bus on Route H32 should be scheduled to stand at any one time.
MEAL RELIEFS: No meal relief vehicles to stand at any time.
FERRY VEHICLES: No ferry vehicles to park on stand at any time.
DISPLAY: Southall, Town Hall.
OTHER INFORMATION: Buses should use the stand in Avenue Road unless full. An overflow stand is available in Cambridge Road. Care should be taken not to obstruct the vehicular entrances to the British Telecom building.

Garage Journeys

From Hounslow Garage to Hounslow, Bus Station:

From garage direct to bus station and line of route.

From Hounslow, Bus Station to Hounslow Garage:

From line of route via London Road to garage.

From Hounslow Garage to Southall Broadway, Town Hall:

From garage via Kingsley Road, Spring Grove Road, Lampton Road, Heston Road, Norwood Road, Merrick Road, South Road, Hamilton Road and Avenue Road to line of route.

From Southall Broadway, Town Hall to Hounslow Garage:

From line of route via Avenue Road, Cambridge Road, South Road, Merrick Road, Norwood Road, Heston Road, Lampton Road, Spring Grove Road, Kingsley Road and London Road to garage.

Authorised Vehicle Types:

Double deck vehicles up to 10 m long.

Single Deck vehicles up to 10.2 m long.